



Reg no: 2017/362363/07  
SA Vat No: 4700280045  
Tax no: 9658182176  
Import/Export Reg No: 21798845

Quick Pitch fitment instructions - Quick Pitch Weather Shade Awning. 180 LHS & RHS, 270 2m LHS & RHS, and 270 LHS & RHS

270 Weathershade awining:



2m Weathershade Awning



180 Weathershade Awning



127 Mosaic street    Mauritz Prinsloo  
Silvertondale    +27 72 125 9343  
Pretoria, Gauteng    mauritz@quickpitchsa.co.za  
South Africa    www.quickpitchsa.co.za

Figure 1:



Figure 2:



Figure 3:



Figure 4:



#### What's in the Box

- 1x Awning 180 (LHS & RHS), 270 2m (LHS & RHS), and 270 (LHS & RHS)
- 1x tightening strap.
- 1x Large flange pop rivet

## Tools Needed

- 1x 13mm Spanner
- 1x 5mm Allan Key
- 5mm drill
- 8mm drill
- Drill

## Method:

1. The stainless-steel hinge has 4 predrilled holes, make sure the bag at the back of the awning is straight and flush with the frame, take a m8 drill and drill through the bag's canvas. (Figure 1)
2. Do not drill through the stainless steel. This is just to pierce the bag to get the bolts through.
3. Take 4 m8 bolts and washers put them through these holes. (Figure 2)
4. Line these bolts up with the holes in the bracket and push them through, take 4 m8 lock nuts and tighten the bolts and nuts through the bracket on the vehicle.
5. Open the awning, line up 2 of the holes in the pan of the awning with the bracket that is on the vehicle, again use the 8mm drill to open the bags canvas for the bolts to go through.
6. Place the bolts through the bracket and tighten.
7. Pull the last arm open, mark the last square tube arm in line with the vehicle and drill a hole with the 5mm drill for the tension strap on the inside of the arm.
8. Make a hole through the webbing, place the pop rivet through the webbing and pop rivet in place.